




Note: DIP switch position 1 on the Receiver must be in the on position to enable Cisco communications.

RTK-AM1 Firmware Update Instructions for AMA Compatability

1. Remove the microSD card from its plastic case.
2. Insert the microSD card into the RTK-AM1-RX front slot.
3. Connect a link cable between the RTK-AM1-RX and RTK-AM1-TX. Apply power to both devices and verify that the Link LED is solid green.
4. Press and hold the Function button for 15 seconds until the green FW LED flashes quickly, then release button.
5. The FW LED will flash quickly in various patterns while the devices update.
6. Firmware update is complete when the FW LED returns to slowly flashing green. This may take up to 20 minutes.
7. Power cycle the RTK-AM1-TX and RTK-AM1-TX.
8. The microSD card can be removed at this point, if desired.

If you have any questions or issues feel free to contact Technical Support at +1 (203) 854-5701, option 3

<https://www.soundcontrol.net/support/>