



Applies to: RC-SDA+™, RC-SDA+ Gen2™

The RC-SDA+™ and RC-SDA+ Gen2™ are similar devices with a few significant differences. One distinction to note is the fact that audio routing options are slightly different, affecting DIP switch settings when migrating to a Gen2 device.

When replacing an RC-SDA+™ with an RC-SDA+ Gen2™ be sure to match all DIP switch settings with the old, with the exception of DIP switch 1. Set DIP switch 1 to the Off (down) position, even if it was On in the original RC-SDA+™.



Then, be sure to plug in all cables from the original installation.

For further details on DIP switch functions please see the “FAQ” and “Audio Routing Options” documents on the RC-SDA+ Gen2™ product page of www.soundcontrol.net.

If you would like further assistance, please contact SCT Technical Support.