






*HP Poly V52 requires the use of an HP USB to Ethernet dongle to enable LLN mode for microphones. See HP Poly documentation for further details.



SCT B.O.M.
• RTK-AM1™

CABLE LEGEND
• SIGNAL TYPES •

- Power
- SCT Link
- Ethernet (PoE)
- Video
- USB 2.0
- USB 3.0/3.2
- Audio

SCT PROVIDES CABLES SPECIFICALLY FOR APPLICATION & DEVICES.