




Camera | Display Location

Logitech Rally Camera



*Note: The Logitech Rally Camera Power Splitter is not required.

RCU3SL-CE™



End Point | Table Location

RCU3SL-HE™



Laptop



CABLE LEGEND
• SIGNAL TYPES •

- Power
- SCT Link
- USB 3.0/3.2

SCT PROVIDES CABLES SPECIFICALLY FOR APPLICATION & DEVICES.