

#### Installation Notes for the RCR-PH1 Recessed Camera Mount

#### Kit Contents:

- Back Box
- Cover Plate
- Camera Mounting Plate
- Hardware bags A D



### Mounting RC3-CE to Cover Plate

• Use Bag A



Rear view of the RC3-CE attached to the cover plate with the finish screw caps installed.

Front view with the screw caps closed.



Back Box with PrecisionHD mounting plate and hardware bag B



Back Box with PrecisionHD mounting plate attached



Back Box with PrecisionHD mounting plate attached and finish screw caps closed



Two major components ready for assembly. Hardware bag C will be used to attach the cover plate to back box.





Cover plate shown attached to back box with camera cables RC3-001 & RC3-002 properly dressed

Cover plate shown attached to back box with finish screw caps closed.

PrecisionHD camera is now ready to be attached to the camera mounting plate with hardware bag D.





PrecisionHD bottom

Camera interface plate attached to the camera bottom with the provided 1/4x20 undercut flat head screw.

PrecisionHD with RC3-001 & RC3-002 cables attached ready for final placement.





Camera shown attached to the mounting plate with finish screw cap closed.



Finished assembly.